

NIGHTHAWK MK62 SETUP MANUAL GUIDE



Scan the QR code to visit our website



TABLE OF CONTENT



01


NIGHTHAWK MK62
SETUP MANUAL GUIDE

02

SYNC MS60 SATELLITE WITH ROUTER

NIGHTHAWK MK62 SETUP MANUAL GUIDE

- Take an Ethernet cable (the yellow one in the box works), plug one end into the modem and the other into the internet port on the router MR60.
- Plug it in the power outlet and wait. Give it 2-3 minutes. It'Il boot up, LEDs will do their thing you're looking for a solid white light eventually.
- Connect to the pre-set WiFi (look at the sticker under the router should be something like "NETGEARxx" and a password).




- Or plug a laptop into the router with another Ethernet cable. Wired is cleaner if you've got one handy.
- ▶ Once you're on the network, open a browser and type: routerlogin.net or 192.168.1.1. Hit Enter.
- If that doesn't load the Nighthawk login setup page? Clear your DNS cache or try another browser/device.
- You should land on the Netgear setup wizard. If not, and you're asked to log in, use:
 - ADMIN
 - PASSWORD



- If it auto-detects your internet and asks to continue setup, go for it. It'II test your connection and then ask if you want to use the Nighthawk app or just do it manually.
- ► The wizard should let you rename your network and set a password. That default stuff is lameand insecure. Name it something fun or normal, just don't leave it as NETGEAR123 or whatever.

SYNC MS60 SATELLITES WITH ROUTER

- Plug in a satellite in the same room where the router is powered on.
 Wait for it to blink orange.
- Press the Sync button on the router. Within 2 minutes, press Sync on the satellite.
- If all goes well, that satellite will go from orange → blinking white → solid white. That's what
- you want. Still blinking orange after 5 minutes? Reset it again and retry.





Thank You

support@night-hawklogin.com



Scan the QR code to visit our website